





Instructions

Winding

With the crown in Position 0, wind the watch about 30 times. This will power the mainspring of your watch. The rotor will continue to wind the watch as you wear it and keep the watch going. The watch has a power reserve of about 40 hours.

Setting the time

Pull the crown out to Position 2 to set the time (hours and minutes). The second hand disk will stop in place when the crown is pulled out to this position. This feature is known as "hacking".

Setting the date and 24 hour hand

Pull the crown out to Position 1 to set the date and 24 hour (GMT) hand. Turn the crown clock-wise to advance the 24 hour hand or counter-clockwise to advance the date.

Only advance the date when the time is after 2 A.M. and before 10 P.M.



Position 1: Date/24 Hour Position 2: Time

Taking care of your watch

Like any other precision mechanical device, your watch needs proper care. In order to protect your investment and to keep it in good working order, please note the following:

Normal sports activities will not affect the watch's integrity. However, any type of violent shock may upset the movement and the watch's ability to keep correct time.

If you have not worn your watch for 24 hours or more, it should be wound about 30 times to replenish its power reserve. Adjust the date of your watch only when the hours hand is below the 2 and 10 o'clock makers. Changing the date with the hands close to the 12 o'clock maker could damage gears in your watch.

The watch itself should be cleaned with a soft cloth and water only. Avoid getting leather bands wet. Metal bracelets should be cleaned with a soft brush and warm soapy water. Then rinsed with clean water and dried with a soft cloth.

Water Resistance

Never wind or pull out the crown when the watch is wet or underwater. The maximum water resistance depth is engraved on the case back. Any watch that is regularly immersed in water should be inspected for water resistance ability every year. Watch cases and bracelets should be rinsed throughly in fresh water after being in salt water. If you notice condensation in your watch, send it to Individual Design or another qualified watchmaker immediately before rust or corrosion occur.

Indicated water resistance is a static tested pressure ability. Activities underwater induce additional pressure on the watch which are greater than the nominal (actual) depth.

Water Resistance Guidelines:

50 Meters / 5 ATM / 165 Feet - suitable for swimming 100 Meters / 10 ATM / 330 Feet - suitable for swimming and snorkeling 200 Meters / 20 ATM / 660 Feet - suitable for recreational scuba diving 300 Meters / 30 ATM / 1000 Feet - suitable for professional diving

Avoid wearing your watch in saunas and hot tubs as the high temperatures can effect the watch's gaskets. Avoid bathing or showering with your watch as soap can reduce the surface tension of the gaskets which are designed to keep water out of your watch.

Warranty

Mark Carson/Individual Design watches are warranted (parts and labor) for one (1) full year from date of purchase for the original, registered owner. Proof of date of purchase is required for warranty claims. Watches purchased directly from Individual Design are automatically registered for warranty p[urposes.

Watch case, crystals, crown, movement, dial, hands, buckles, metal bracelets

Not Covered:

Watch straps/bands (other than metal bracelets) Scratches, breakage or other customer caused damage or loss

Watch bands are warranted to be free from manufacturing defects at the time of purchase but are not otherwise warrantied as they are normal "wear and tear" items.

Leather watch bands typically have a finite life as perspiration and body oils degrade natural leathers over time. It is not unusual to replace your watch band annually.

Return Policy and Service

Do not return any items to Mark Carson/Individual Design without first getting a Return Merchandise Authorization (RMA). Contact Mark Carson/Individual via email (Service@MarkCarson.com) for an RMA.

Watches with manufacturing defects will be repaired or replaced or a full refund made to the original purchaser (including shipping both ways).

Service: For service to a watch which has passed its original warranty period, contact Mark Carson/Individual Design prior to shipment:

Service@MarkCarson.com